

The GS-10's Self-Test

Version 0.2.0; March 14, 2013.
Copyright © 2013 by Mark van den Berg.

This document attempts to describe the BOSS GS-10's self-test procedure.

With the GS-10 switched off, hold the DELAY TAP button and the button below CHORUS LEVEL, then press the POWER button at the back:

First the display flashes "SRAM check...".

Then it says:

```
GS-10  
Ver. 1.00 [D749]  
Press EXIT.
```

1.EEPROM Check

The display flashes "Now Checking...".

Then it says:

```
V1.00 Sum[C548]  
Press EXIT.
```

2.DSP Check

The display flashes "--- OK! ---" and goes to #3.

3. All the cells in the display and all the LEDs on the buttons light up.

Press EXIT.

4.LCD Contrast

```
Contrast=15
```

Rotate the PATCH/VALUE knob to the left until the display says Contrast=0, then rotate the knob right, back to "15", upon which the display goes to #5.

5.Switch

```
PREAMP
```

Press the PREAMP button: its LED goes out and the display says:

```
CH SEL A
```

In this way you process all the buttons.

After the final button (SPEAKER), the display goes to #6.

6.VR Check

```
Set VR to Min
```

Move the GAIN knob fully to the left, upon which the display says:

```
PRE GAIN : 0
```

Then you rotate the GAIN knob fully to the right until the display says "255", upon which it

goes to "PRE BASS".

Act similarly for all the knobs on the left side of the GS-10. (Note that the PATCH/VALUE, AUX INPUT LEVEL and OUTPUT LEVEL buttons are *not* covered here!)

After the last knob the display goes to #7.

If you've connected the EV-5 expression pedal, the display says:

```
7.SUB EXP PEDAL  
[---] [-*-] [---]
```

Press the pedal fully down, upon which the display says:

```
[-*-] [***] [***]
```

Lift the pedal fully up, upon which the display flashes:

```
[***] [***] [***]
```

... and the display goes to #8.

However, when *nothing* is connected to the EXP/CTL PEDAL socket, the display says:

```
7.SUB EXP PEDAL  
CTL 1      On
```

If you then connect a CTL 1 pedal, you can switch between "On" and "Off" by pressing the CTL 1 pedal.

However, you can't reach #8 this way: you *must* connect an EV-5 to do so.

8.Battery

```
n.nV
```

(Ideally this should say "3.0V". In my experience the GS-10 accepts values down to 2.7V.

Once the value goes down to 2.6V, the GS-10 starts up saying "Battery Low !!

Please Change". Refer to my document 'GS-10 battery.pdf' for instructions on battery replacement.)

Press EXIT.

9.MIDI IN/OUT

As long as you have *not* looped a MIDI cable from the GS-10's MIDI IN to the GS-10's MIDI OUT, the display says:

```
No Connect
```

Once you do loop a cable from MIDI IN to MIDI OUT, the display briefly says "- Verify OK! -" (or so), then goes to #10.

10.OUTPUT D/A

The display toggles automatically (at an interval of about 2 seconds) between

```
Mute Off/--
```

and

```
Mute ---/On
```

(I'm not sure whether you're supposed to *hear* anything in any way.)

Press EXIT.

11.DIGITAL OUT

Same story as 10:

```
Mute Off/--
```

```
Mute ---/On
```

12.SPEAKER OUT

[DSP---->OUT]

The SPEAKER button's LED is now on and the GS-10's speakers are outputting a continuous tone (a sine wave of about 175 Hz?): use the OUTPUT LEVEL knob to set the volume.

Press EXIT.

13.AF GAIN

[GTR --->OUT]

Press EXIT.

14.GTR INPUT A/D

[GTR --->OUT]

Press EXIT.

15.MIC INPUT A/D

[MIC---->OUT]

Press EXIT.

16.AUX INPUT A/D

[AUX---->OUT]

Press EXIT.

17.AUX MIX OUT

[AUX->MIXOUT]

Press EXIT.

18.DSP INTO

"--- OK! ---" or so; automatically to #19.

19.Noise (IN->OUT)

[IN----->OUT]

Press EXIT.

20.USB OUT/IN

If the USB cable is connected to the GS-10 (not necessarily connected to a computer), you get:

USB RETURN-->OUT

If the USB cable is not connected to the GS-10, you get:

No Connect

Press EXIT. (This is possible even with 'No Connect'.)

21.Factory Load

press [WRITE]

You can now either switch off the GS-10 by pressing the POWER button, or press WRITE.

If you press WRITE, the display asks "Sure ?"

If you then press WRITE again, the display briefly says Now writing... (or so), then:

Test Completed !

Turn Power OFF

Press the POWER button.